

Technical information

Ctn. of 12×1 litre bottles order No. 00157 Ctn. of 12×1 litre re-fillable packs order No. 00155 10 litres canister order No. 30154 1.5-litres pressure-sprayer (empty) order No. 80257 3-litre spraying-device (empty) order No. 88893

High-performance wiping

Area of application

Suitable for cleaning and maintaining all water-resistant floorings such as linoleum, PVC, rubber, olefin, sealed wood / parquet / cork, laminate, artificial and natural stone tiles. For coated and uncoated water-resistant floor coverings. Applicable for ALL cleaning methods.









Application

Maintenance cleaning: Machine cleaning: 0.5-1 % Spray cleaning: 1.3 % Manual cleaning: 0.25 %

Note: Prepare the cleaning solution with clean, cold water.

Intermediate cleaning / treatment:

- Initial treatment and initial care: Dilute 1:10 with clean water (10%), wipe the clean surface and polish after drying (high-speed polishing machine).
- Spray cleaners: Dilute 1:3 with 1:5 clear water, partially apply with spray cans and work surface with polishing machine (400-450 rev/min.).
- Intermediate cleaning: Dilute 1:10 with clean water (10%), apply solution, work mechanically, for example, with single-disc machine, pick up dirt leftovers and polish after drying (polishing machine to high-speed polishing machine).





Product characteristics

- Cleaning, care and revitalisation in one operation
- Pronounced spraying capability and high dirt dissolving power
- Suitable for anti-static coatings when used properly
- Tested according to DIN 18032
- Streak-free shine can be polished to a high gloss
- Non-skid care film with no-build-up effect
- Pleasant room freshness

Never wipe sealed wood / parquet flooring, cork and laminate flooring wet! Always only damp with low residual moisture.

All information contained in our brochures is accurate to the best of our knowledge and experience. No liability can be derived from the information herein. For details about the product, please refer to the safety data sheet. GB 1118

pH conc 0 2 4 6 10 12 14

DR.SCHNELL GmbH & Co. KGaA

Taunusstraße 19 · 80807 Munich Tel. +49 89 3506080 info@dr-schnell.com www.dr-schnell.com

