

Technical information

FOROL

IOROE	
Carton of 12 x 1 bottles	order No. 00114
Carton of 12 x 1	
re-fillable packs	order No. 00385
10 canister	order No. 30017
Carton of 10 packs of	
10 x 4 ml cartridges	order No. 00817
Carton of 12 x 600 ml	
hand sprayers (empty)	order No. 00885
1.5 pressure sprayer (empty)	order No. 80211

FOROL FRUIT

Carton of 12 x 1 | bottles 10 | canister



Multi-purpose cleaner

Area of application

Suitable for the effective cleaning of all water-resistant, smooth and textured surfaces; also for coated and uncoated, water-resistant floor coverings. Applicable for ALL cleaning methods.



Application

Maintenance cleaning Manual cleaning: 0.25 % Spray cleaning: 0.25–0.5 % Machine cleaning: 0.5 % Note: Prepare the cleaning solution with clean, cold water.

Intermediate and basic cleaning:

 Intermediate/post construction cleaning:
Floor: Dilute 1:20 with clean water (5 %), work the cover surface
with product solution and cover-specific mechanics, afterwards vacuum
the dirt leftovers thoroughly

 Spray cleaners: Dilute 1:20 with clean water (5 %), partially apply with spray cans and work surface with polishing machine (400–450 rev/min.)

Product characteristics

order No. 00515

order No. 30517

- Modern and reliable cleaning in one operation
- Synergistic surfactant excellent soaking capability and high dirt dissolving power
- Optimises the functionality of modern cleaning methods:
 One step working with folding technique
- Cloth and mop-change method
- Systems with pre-saturated cleaning cloths
- Supports the effectiveness, especially of micro-fibres, with regard to dirt entrainment capacity
- Suitable for anti-static surfaces
- Two attractive fragrance creations to choose from
- Excellent material compatibility on marketable perspex up to max. 5 %

All information contained in our brochures is accurate to the best of our knowledge and experience. No liability can be derived from the information herein. For details about the product, please refer to the safety data sheet. (GB) 0917

pH conc 0 2 4 6 8 12 14



Taunusstraße 19 · 80807 Munich Tel. +49 89 3506080 info@dr-schnell.com www.dr-schnell.com

